160R-1.8 / 180R-1.8



PARTS NO.	SPECIFICATION	PARTS NO.	SPECIFICATION
① SP-334	BOLT,WASHER & NUT FOR 160/180ZR SERIES	⑫ SP-352	HOLDING DEVICE FOR THE COUNTER BLADE
② SP-74	SCREW,NUT &2 WASHERS FOR THE HOOP OF		WITH 2 SCREW FOR 160ZR
	ZR SERIES/160R-1.8/180R-1.8	⑬ SP-353	SCREWS FOR HOLDING DEVICE OF 160ZR/
③ SP-392	ROD FOR 160R/180R-1.8		160R-1.8 (4PCS)
④ SP-338	ROD FIXING PART FOR ZR/160R/180R SERIES	⑭ SP-379	CENTER BOLT & NUT FOR GRIP OF ZR SERIES
⑤ SP-339	SLEEVE FOR THE GRIP OF ZR/160R/180R SERIES	⑮ SP-380	HANDLE LATCH LOCK SET FOR ZR/160R/
⑥ SP-393	PIPE FOR 160R/180R-1.8		180R SERIES
⑦ SP-399	SCREW TO ATTACHED CUTTING BLADE FOR	⑯ SP-400	STOP SCREW & NUT FOR 160R/180R
	160R/180R (2PCS)	⑰ SP-348	GRIP SET FOR 160/180ZR
⑧ SP-41	SPRING FOR LONG REACH PRUNER	⑱ SP-414	NUT CAP FOR THE HANDLE OF ZR/160R/
	(INC ZR SERIES,150-0.6) (1 PC)		180R SERIES
⑨ SP-349	GRIP LEVER ONLY FOR ZR/160R/180R SERIES	⑲ SP-418	SLEEVE FOR STOP SCREW & NUT OF 160R/
⑩ SP-350	MIDDLE GRIP FOR ZR/160R/180R		180R-1.8
⑪ SP-351	HOLDING DEVICE FOR THE CUTTING BLADE		
	WITH 2 SCREW FOR 160ZR		